

Westell Wireless Modem/Router Security Set-up

Open browser

Type in 192.168.1.1

Configure

—Wireless

——Security

Select **WPA-PSK**

WPA Shared Key - *type in a password with at least 8 characters*

WPA Group Rekey Interval - 3600

Save

Westell Wireless Security Set-up for Vista

Open browser

Type in 192.168.1.1

Configure

—Wireless

——Security

Select **WPA-PSK**

WPA Shared Key - *type in a password with at least 8 characters*

WPA Group Rekey Interval - 3600

Save

Go to **Control Panel**

Network and Internet

Network and Sharing Center

Manage Wireless Networks

—Right click on your Westell wireless connection

—Left click on Remove Network

Connect to a Network

Select the Westell network and type in your password

Do not save Network Connection